





# Find the Tool you need

RECOMMENDED FOR				FLOOR THICKNESS / TOOL SERIES							TYPE	FASTENER TYPE			
Solid	Engineered	Engineer/Click***	Bamboo***	1/4" / 6 mm	3/8" / 8 mm	1/2" / 12 mm	5/8" / 15 mm	3/4" / 19 mm	7/8" / 22 mm	33/32" / 23 mm		Nails L	Nails T	Staples	
															
	X	X			Q180 Stapler										
X	X		X		500 & 510 Nailers							18 ga nailers & 1/4" stapler			
X	X		X		550A & 550AR Nailers										
X	X				300* & 330* Nailers							16 ga nailer & 15 1/2 - 1/2" crown stapler			
X	X				245F* Nailers										
X	X				245FR*										
X	X				250F* Nailers & Staplers										
X	X				250FR										
X	X				250A & 250AR Nailers & Staplers										
X	X				250 Gym's Nailers & Staplers										

\* with optional base

**PRIMATECH DISCLAIMER**

Be it raw, factory finished or engineered, hardwood is a natural material subject to various factors (humidity, subfloor, installation procedure, type of tools and fasteners, etc.). Installer should always ensure optimal surface preparation, comply with all the manufacturer's recommendations and conduct a pre-installation test before beginning the actual flooring work.

Some Click or Bamboo :  
Installer should always comply with all the manufacturer's recommendations.