




## Q-993E Piston

FOR Q900A PNEUMATIC NAILERS

If piston/driver assembly is removed, it must be reinserted in the same direction. (As shown)

**POUR LES CLOUEUR Q900A**

Si l'assemblage piston/lame est désassemblée, le réinsérer dans le même sens. (Voir image)



**IMPORTANT**  
Insert the piston assembly  
with the driving blade  
as shown.

Printed in Canada

05/18




## Q-993E Piston

FOR Q900A PNEUMATIC NAILERS

If piston/driver assembly is removed, it must be reinserted in the same direction. (As shown)

**POUR LES CLOUEUR Q900A**

Si l'assemblage piston/lame est désassemblée, le réinsérer dans le même sens. (Voir image)



**IMPORTANT**  
Insert the piston assembly  
with the driving blade  
as shown.

Printed in Canada

05/18